



NOTES:

1. COORDINATE MAILBOX LOCATION WITH LOCAL POSTMASTER AND ENSURE MAILBOX DOES NOT WITHIN SIGHT TRIANGLE.
2. INSTALL USPS APPROVED MAILBOX ONLY.
3. PAINT CURB YELLOW 20' BEFORE MAILBOX AND 10' AFTER MAILBOX.

NO SCALE



APPROVAL

*Wayne R. Hayde*

PUBLIC WORKS DIRECTOR

<b>MAILBOX SIDEWALK TRANSITION</b>	
DATE	01/21/2022
DRAWING NO.	ST-19
REV:	